

ComAnt CAC3 Application Installation

THE MAST SHOULD OVERLOOK THE DIPOLE END

For proper weather protection all connectors and cable junctions should be covered by self-amalgamating tape or equivalent

Direction of maximum radiation

Splitter harness shall be tied to the mast after the installation

2 Pcs CS

3 Pcs CAD

$$S \text{ [m]} = 300 / f \text{ [MHz]}$$

